

## Basic Biometric Clock: How to Punch

From the Idle screen on the clock, use the keypad to enter the Clock ID and then press the Enter (check mark) button



On the punch screen, press the F2 key next to Punch to insert a punch to the system



You will see confirmation of the punch on screen. Congratulations, you have successfully punched on the Basic Clock