

Basic Clock: Setup WIFI

On First boot of the clock, You will be at the factory Setup screen. Press the F4 button to Exit



Then Press the F8 Key (next to the gear)



Enter 1905 for the PIN



Use the Arrows to scroll to Settings and Press Enter (check mark)



Scroll to Network and press Enter



Scroll to Interface and press Enter



Scroll down to Wireless LAN and then press enter (confirm choice)



Scroll to SSID and Press Enter. Select the name of your Network and press Enter



Scroll to Key Management and press Enter



Select WPA and press enter



Enter the password for the network using the keypad. You may need to press buttons multiple times for each letter. For example, entering the letter F, press the 3 button 3 times, etc. Once the password is entered, press Enter button

